




[Driver Installation for Mac OS X 10.10]


1. Insert the installation CD and run. Open the 'MAC_Installer' folder and run the 'Installer OS X.pkg file'.




- 1-1. If you download over the Web, please unzip the file. Go to the 'PrinterDriver > MAC_Installer > MAC_Printer' path and run the 'Printer Driver.pkg'.



2. If the installer asks for a password, enter your user password.



3. The installation is completed.




[Add a printer using the Socket protocol]


1. Run the 'System Preferences' from the Dock at the bottom.




2. Click the 'Printer & Scanners'.



3. Click the '+' button.



4. Select the 'IP' at the top and choose a 'HP Jetdirect- Socket' in the 'Protocol' field.




5. Enter the printer's IP in the 'Address' field, and enter the printer name to be used in the 'Name' field.

The screenshot shows the 'Add' printer window in macOS. At the top, there are three tabs: 'Default', 'IP', and 'Windows'. The 'IP' tab is selected and highlighted with a red box. Below the tabs, there is a search bar with a magnifying glass icon and the text 'Search'. The main area contains several fields: 'Address' with the value '127.0.0.1' (highlighted with a red box), 'Protocol' set to 'HP Jetdirect - Socket', 'Queue' (empty), 'Name' with the value 'test' (highlighted with a red box), 'Location' (empty), and 'Use' set to 'Generic PostScript Printer'. A warning message below the 'Use' field states: 'The selected printer software isn't from the manufacturer and may not let you use all the features of your printer.' At the bottom right, there is an 'Add' button.


6. The printer driver is selected automatically in the 'Use' field. If not automatically selected, click on the 'Select Software...'.

The screenshot shows the 'Use' field dropdown menu in the 'Add' printer window. The menu is open, displaying a list of printer drivers: 'Auto Select', 'Generic PostScript Printer' (which is selected and has a checkmark next to it), 'Generic PCL Printer', 'Select Software...', and 'Other...'. The 'Name' field above the menu contains the text 'test'.


7. Search and choose the driver to install. And click on the 'OK'.



8. Click the 'Add' will add a printer.



9. Add the printer is complete.



10. When you open the print window in the document (shortcut : cmd+p), you can check the printer.

